LSE Estates Division

# Space Information User Guide

How to access space information and floor plans on Planon

For more information, contact the Estates Systems Admin team: **Chris Anderson** (Systems Manager), <u>c.anderson2@lse.ac.uk</u>, ext. 7912

# **Space Information User Guide**

This user guide is aimed at helping Planon users to access the features of Space Information for typical enquiries, such as printing floor plans and tables.

To open the table of contents for navigating through this guide click the **View** tab above and tick Navigation Pane:

		5.		space information and noor Hans, dock - Microsoft Word									
File	Home	Insert	Page Layout	References	Mailings	Review	View	EndNot	e X7				
Print Layout	Full Screen Reading	Web Outlin	e Draft	Ruler Gridlines Nargation Pane	<b>Q</b> Zoom	100%	One Page Two Pages Page Width	New Window	Arrange	Split	View Side by Side 폐‡ Synchronous Scrolling 현국 Reset Window Position	Switch Windows *	Macros
	Docum	ent Views		Show		Zoom					Window		Macros

# Java client and Web client

There is a planon java client that runs on the desktop and a planon web client that runs in a browser such as Internet Explorer / Chrome/ Firefox. The screenshots are taken from the java client. All users are moving to the Web client. The screens are slightly different. Options may appear in a different place but all the instructions are the same unless otherwise stated.

# Finding space information

On the left hand side menu **Launch centre**, information about spaces in the properties around campus can be found under the group **01 Spaces**. Click on **01 Spaces and Floor Plans** to find space information.



Figure 1 - Selecting 01 Spaces and Floor Plans in Launch Centre

If looking for information in one specific LSE property, select it under the arrow tab **Properties**. The next arrow tab, **Components**, shows the floors available in the building(s) selected. If looking to see building as a whole, click on **Spaces** arrow tab.

Properties Componer	nts	Spaces	$\rangle$	Space details	$\rangle$		
Properties							
Properties (47)	General	Characteristics	Audit info				
LSE Campus, London	Gener	al					
📠 1 Portsmouth Street, London	Prop	erty code *	32L	32L			
💼 20 Kingsway, London	Prop	erty name *	32 Li	32 Lincoln's Inn Fields			
32 Lincoln's Inn Fields, London	Pare	nt level	HOU	I SE Campus	(D)==		
14 Lincoln's Inn Fields, London	Para	nt lovel for bonchma	rke	, LOL Oumpus			
1 50 Lincoln's Inn Fields, London	Tale	increven for Derichman	D. J.		120 100		
5 Lincoins inn Fleids, London	Type		Duild	Building			
95 Aldwych, London	Statu	IS	0	F10, In management	1		
Aldwych House, London		±:					
Centre Buildings Project, London	Bench	marks					
🛍 Clement House, London	Cod	e	Na	ime			
📠 Columbia House, London							

Figure 2 - Selecting the chosen property

#### Example 1: Locate room B.09 in 32LIF

- 1. Under Launch Centre, click 01 Spaces and Floor Plans.
- 2. Under Properties arrow tab, select 32 Lincoln's Inn Fields.
- 3. Under **Components** arrow tab, on column **Floor.Code**, select **-1**.
- 4. Under Spaces arrow tab, select room under Space number.
- 5. Planon should now show the information for the space selected on the right hand side of the screen, as illustrated below.

<u>P</u> lanon F	ProCenter <u>T</u> SI <u>E</u> di	t <u>V</u> iew Sp <u>a</u> ces <u>C</u> AD	D Integrator <u>H</u> elp					
<₽ ◆	🗢 🚺 Refresh	list 😭 Alarm(s)	🐱 Reference date (	Tod	ay) 🏴 Deactivate	reference d	late 🎽	CAD Integrator 🛛 📰 🤇
<u>S</u> ear	ch Department	=			🖋 🔍 Eilter No filte	91		▼ ※ ※ ※ ▼
	Properties	Component	s S	pac	es S	pace detail	s >	History
Spac	es Floor attributes			ſ				
32 Li	ncoln's Inn Fields. L	ondon / Basement			Space inform	nation		
Pro	Floor.Floor.Co	. Space number \land	Name		Permit / hazard in	formation	Audit info	1
Space	es (82)				General	Clea	ning	Dimensions
32L	-1	B.07	Conference		L		-	
32L	-1	B.08	Plant		General			
32L	-1	B.09	Teaching		Property *		32L.	32 Lincoln's Inn Fields
32L	-1	B.10	Teaching		Eloor *		1 B	acomont
32L	-1	B.11	Teaching		11001		-1, D	asement
32L	-1	B.12	Break Out Space		Space number	×	B.09	
32L	32L   -1   B.13   Seminar Room   Name   Teaching							

Figure 3 - Selecting room B.09 in 32L

#### **SUGGESTIONS & TIPS**

- To see all campus buildings, select LSE Campus, under Properties arrow tab.
- To see all rooms in a building, select a building and then jump straight to **Spaces** arrow tab.

• To see the rooms in several buildings at one time (but not all), press and hold **Crtl** key and click on the buildings required to select them (in yellow). Then click the **Spaces** arrow tab

# **Viewing floor plans**

To view floor plans, select any room in the list under **Spaces** arrow tab and click on the **CAD Integrator** tool, found on the top toolbar. Planon will now show a simple floor plan, with the selected room highlighted.





Figure 5 - Selecting CAD Integrator menu

Select the option **Highlight spaces from list**. Planon will now show all the room numbers in the floor plan.

<u>C</u> AD Integrator	<u>H</u> elp								
✓ <u>H</u> ighlight the	✓ <u>Highlight the selected space (on/off)</u>								
Highlight <u>s</u> pa	Highlight <u>s</u> paces from list								
Space <u>m</u> app	Space <u>m</u> apping <u>R</u> epeat the last space mapping (Departments) Ctrl+F3								
Repeat the la									
Link space		Ctrl+F8							
<u>U</u> nlink space	)	Ctrl+Shift+F8							
Show linked	Show l <u>i</u> nked spaces Show u <u>n</u> linked spaces								
Show unlinke									
Rea <u>d</u> in space dimensions									
Define <u>t</u> ext p	oint for space								
<u>P</u> eople per s	pace								
<u>A</u> sset per sp	ace								
R <u>e</u> set drawin	Ig	Ctrl+Shift+F5							
Delete all ref	erences t <u>o</u> Planon data								
La <u>y</u> ers		•							
Show constr	uctional drawing								
Show CAD Ir	ntegrator in separate pane								
Sa <u>v</u> e as		Ctrl+S							
Print									
CAD Integrat	or settings								

Figure 6 - CAD Integrator menu

To turn on constructional features, such as staircases and doors, tick **Show constructional drawing** in the **CAD Integrator menu**. This feature will now be enabled for future use.



Figure 7 - Floor plan with highlighted spaces and constructional elements

To zoom in and out, use the **CAD Integrator toolbar** at the bottom right of the screen.



To turn off the **CAD Integrator** tool, click the button on the top toolbar and the screen will revert back to space information only.

### **SUGGESTIONS & TIPS**

- To see the room number and name, hover the mouse over the space.
- To change colour of the selection, select CAD Integrator settings in the CAD Integrator menu and change Highlighting colour (click on the list button of far right to access colour options).

		1
Yes	No	
		1
		I =
		1
		1
Yes	No	
-		/ 💷
Horizontal		
NetArea, Net area		De
		1
		L
	Ves Ves Horizontal NetArea, Net area	Ves No Horizontal NetArea, Net area

Figure 8 - Changing the highlighting colour

 To include room sizes in the information that you see on the drawing click the selection box for Texts – spaces on the CAD integrator settings and then select the option DO\_SpaceN IA.

dit info	Audit info				Texts - spaces	
General					Name	Contains
Title co	olour *			/ III / III / III		
Automa	atic colouring *	Yes	No		Nama A	
Backgr	round colour *			/ 🖃		presence
Backgr	ound colour text point				DO_Cleaning f	requency
Legend	i colour *			<u>/</u>	DO Cleaning t	vpe
Highligh	hting colour *		less	<u>/</u>	DO Floor finis	hina
Load to	ooltips *	Ves	le No		Do SpaceNan	ne
Colour	for unspecified space			<b>/</b>	DO SpaceNIA	
Colouri	ing direction	Horizontal			DO-CAD-Spac	el Isage
Area ty	pe for space mapping *	NetArea, Net a	irea		DO-CRF Rent	able units
Floor					DO-FM Service	e level
Tooltips	s - floors					
Spaces						
Texts -	spaces			JE		
Tooltips	s - spaces					
Text co	olour - spaces *					
Show u	unspecified space usa	Ves	No			

	Properties	$\rangle$	Components
Spaces			
Propert	y.P Floor.Floo	. Space	^ Name
Spaces	(5811)		
RB	05	R502	
RB	05	R502A	
LRB	05	R503	
RB	05	R503A	Accessible
LRB	05	R504	
RB	05	R505	Conferenc
RB	05	R505A	
RB	05	R506	Office
RB	05	R507A	-
RB	05	R509	Office
RB	05	R510	Office
RB	05	R510A	
RB	05	R512A	
RB	05	R512B	
RB	05	R513	
RB	05	R5134	
RB	05	R519	Office
RB	05	R520	Office
RB	05	R521	Office
RB	05	R522	Office
RB	05	R523	Onice
RB	05	R520	Office
	05	DE26	Office
	05	R020	Office
	05	R020	Office
	05	R527	Onice
LKB	05	R528	
	05	ROLF 11	
LKB	05	R5LF12	
LKR	05	R5LFT3	

This will be enabled for future use.

To remove room sizes from the drawings select DO\_SpaceName.

- To see the floor plan in a separate window, select **Show CAD Integrator in separate pane**, under the **CAD Integrator** menu.
- To remove any changes you have made to floor plan (such as highlighting all spaces), select **Reset drawing**, under the **CAD Integrator** menu.
- If the image on the **CAD Integrator pane** has not changed when selecting a different building, ensure that a space is selected to see new drawing. The floor plan of previous area remains in CAD integrator viewer until you click on a new space.

# **Printing floor plans**

There are two options for printing from Planon. The first, directly printing from the CAD Integrator menu is quicker. The second, saving the floor plan as a PDF file first, produces better quality images.

#### **Printing from Planon**

The floor plan that you are viewing can be printed by selecting **Print**, under the **CAD Integrator** menu. Note – this option does not exist in the Web client. Instead click the PDF

button  $^{\textcircled{\mbox{\footnotesize em}}}$  on the far right of the control panel in the diagram viewer.

To print the whole floor, select **Print range – Complete drawing**. To print only the section of the image seen on the screen select **Print range – Visible part of drawing**.

Print destination	\\Equitrac1\	Follow-You Pr	inting	
Professional title				
POR 1 Portsmo	uth Street / 0	1 First Floor		ţ
Print range				
Complete dr	awing			
OVisible part	of drawing			
Scaled printing-				
Scaled print	ng 1 mm =	1000	<b>*</b>	mm
		(returns	1 pages)	
Print to fit pa	ige			
	und schitz			
Z Print backgrou	11111 10/11111			

Figure 9 - Options for printing directly from Planon

#### **Saving as PDF**

To obtain better quality images, the best practice is to save as PDF first. To do so, select **Save as...**, under the **CAD Integrator** menu, and change to settings as below. Note – this option

does not exist in the Web client. Instead click the PDF button on the far right of the control panel in the diagram viewer.

Field	Best settings
File type	PDF
Printing range	Complete drawing (if wishing to print whole floor)
Page size	A3
Orientation	Landscape
Scaling	Fit to page

The PDF file will be automatically be saved into the H:\ drive. Its location can be changed by clicking on the button to the right of the **File name** field (which can also be modified).

File type	PDF 💌		
Printing ra	ige	Visible part of drawing	
	t options		,
Title	POR 1 Portsmou	th Street / 01 First Floor	ļ.
Page size	A3	*	
Orientation	O Portrait	<ul> <li>Landscape</li> </ul>	
🗹 White	packground		
🗹 Open e	xported PDF file		
Scaling —			
Fixed s	cale: 1 mm = 10	000 • mm	
Fit to p	age		
File name			

Figure 10 - Saving a clearer image and changing the file location

Once the file is saved, it should automatically open in a new Adobe Reader window and it can be printed as a PDF file from the same program.

#### **Example 2: Print a floor plan of 32LIF Basement**

- 1. On the Properties arrow tab, select 32 Lincoln's Inn Fields.
- 2. Under the **Components** arrow tab, select **Floor** (if not already selected).
- 3. On column Floor.Code, select -1.
- 4. Go to the **Spaces** arrow tab and select any space.
- 5. Turn on **CAD Integrator** (if not already on). The CAD Integrator view pane should now show a floor plan of the basement of 32 Lincoln's Inn Fields.
- 6. Use the **CAD Integrator menu** to modify the drawing (e.g. **'Highlight spaces from list'**) as necessary.
- 7. Under the CAD Integrator menu, click on **Save as**, selecting file type **PDF** and other best options for printing (see **Saving as PDF** section).
- 8. A new **Adobe Reader** window showing the PDF file should now be open. If it has not automatically opened, file can be found in H:\ drive (or any other location where it was saved).



Figure 11 - 32L Basement floor plan seen on Adobe Reader

- 9. To print the drawing, select **Print** under **File** menu in the Adobe Reader window.
- 10. The file should now be ready to print.

# **Searching for spaces**

You can search for spaces by criteria such as **Department**, **Floor**, **Space name** and **Space number**. The **Search** bar is located under the toolbar and above the arrow tabs.



Figure 12 - The search bar on Planon

If looking for rooms throughout the campus select **LSE Campus** under the **Properties** arrow tab. Then jump to **Spaces** arrow tab. Using the search function, select the desired category to search, use search operators and if needed add information to the field on right.

Click the **magnifying glass** to activate the search. The search fields are now in yellow to show that the search is active.

Search	Space number		Contains 🔽	B.0	1	ø	Q	<u>F</u> ilter
P	roperties	Com	iponents		S	paces		
Spaces F	Floor attributes							
LSE Cam	pus, London							
Property.	Pr Floor.Floor.	Space nu	Name 🗸		General	Cleaning	Di	mensio
Spaces (4	6)							
TW1	-1	B.01	WC - Disus		Genera	al		
32L	-1	B.01	Teaching		Prop	erty *		
TW3	-2	SB.01	Switch Room		Floor	*		
SAW	-1	B.01	SU Venue		Space	o number *		

Figure 13 - Searching for rooms that have 'B.01' on their space number

#### **Example 3: Find the Harvard Lecture Theatre on campus**

- 1. Under **Properties** arrow tab, select **LSE Campus**.
- 2. Jump to **Spaces** arrow tab.
- 3. On the search bar, select Name.
- 4. On the search operator, select **Contains**.
- 5. On the field next to it, write 'Harvard'.
- 6. Click on the **magnifying glass** icon.
- 7. Planon should now show a list of rooms named Harvard.
- 8. To remove the search, click the **eraser** icon.

Search Name	<b>•</b>	Contains 🔽 Harva	ard 🛷 🔍 Ei
Properties	Cor	nponents	Spaces
Spaces			
LSE Campus, London			
Property.Property code	Floor	Space number	Name 🗸
Spaces (2)			
32L	00	G.03	Harvard Lecture Theatre
32L	-00	LG.04	Harvard Lecture Theatre

Figure 14 -Results of search for Harvard Lecture Theatre

#### **Using filters**

It is possible to filter results using the **Filter** function to the right of the search field.

A filter is in effect a search that has been saved with a name, so you can just select it from the drop-down list instead of re-entering the search fields each time.

Select a filter and it is highlighted in yellow to show that it is active. **No filter** is the default option.

Search Dep	artment	-		== <b>/</b>	🔍 Eilter	Vacant	- 📀 🆗 🖗 T	
Propertie	s > Ca	mponents	$\rangle$	Spaces	s	pace details	History	
Spaces								
Property.P	Floor.Floo	Space nu	Name	~	Permit / ha:	zard information	Audit info	
Spaces (10)			27		General	Cleaning	Dimensio	
OLD	02	2.09	Store					
SAR	-1	B.07	Store		General			
SAR	-1	B.06	Store Office - Ope Office Office Office Office Meeting / S		Property * Floor * Space number * Name			
TVV1	11	11.01						
KSW	04	4.13						
KSW	04	4.10						
STC	03	S364						
STC	05	S565			Space start date *			
TW2	05	5.01a			Space and data			
OLD	03	3.40			Space e	no date		
					Net inte	rnal area (EMR)		

Figure 15 - Filtered search for vacant spaces and its results

#### **SUGGESTIONS & TIPS**

- If the filter you want is not in the list, ask the Estates system administrators if they can create it.
- It is easy to leave a search or filter on by mistake. If you do not see all the spaces you expect check if the search or filter bar is highlighted in yellow.

# Selecting by type or by department

Planon also allows users to see space information according to the space type and department. Like **Floor**, these are accessible under the **Components** arrow tab.

#### Under the **Components** arrow tab, select **Space Types** or **Departments**.

Properties	Components	Spaces	Space details
Floors Zones Space categori	es Space types / Charge back	Departments Cost centres	Tariff groups Space types

Figure 16 - Selecting Departments or Space Types under Components

By selecting one type only, and then going forward to **Spaces** arrow tab, it is possible to see rooms under the selected category, i.e. all spaces with the same type and all spaces belonging to same department.

Search Space type	, <b>T</b>	In 🔽	== 🏈 (	Contraction Eilter	
Properties	) Ca	omponents	Spaces		
Spaces					
LSE Campus, London / PRFS, ALS, LSE Language Centre, 220, \$BF00FF					
Property.Propert	Floor.Floor.Code	Space number	Name 🗸	Permit /	
Spaces (32)				Gen	
TW3	03	3.01C	Tutorial		
TW3	03	3.01D	Tutorial	Gene	
EAS	06	C620	Teaching	Pro	
EAS	06	C622	Teaching	F 10	
EAS	08	C804	Staff	FIOC	
EAS	08	C805	Resource	Spa	
EAS	07	(C722A)	Reception	Nan	
EAS	07	C722	Reception	Spa	
EAS	07	C721	Quiet Room	Spa	
TW3	03	3.01E	Quiet Room	Not	
TW3	03	3.01	Office - Open Plan	Ivet	
KSW	00	G.03B	Office	Space	
EAS	05	C520	Office	Star	
EAS	05	C519	Office	Otai	

Figure 17 - Language Centre rooms on campus

#### **Space mapping**

Floor plans in Planon can show different space types or departments by using different colours on the drawing. To do that, under the **Spaces** arrow tab turn on **CAD Integrator** and in its menu select **Space mapping**, then select **Space Types** or **Departments**.

<u>S</u> paces	CAD Integrator Help		2
1 Alarn	✓ Highlight the selected space (on/off) Highlight spaces from list	e date 🛛 🝓 CAD Integrator	
	Space mapping Repeat the last space mapping (Departments Link space Unlink space Show linked spaces Show unlinked spaces Read in space dimensions	) Ctrl+F3	Space categories Departments Departments Level 1 Departments Level 2 Departments Level 3 Space classifications Cost centres Tariff groups spaces
	Denne text point for space People per space Asset per space Rgset drawing Delete all references to Planon data Layers ✓ Show constructional drawing	Ctrl+Shift+F5	Space types Eree space attribute Sp <u>a</u> ce occupancy Available <u>w</u> orkspaces User-defined space mapping
	<ul> <li>Show CAD Integrator in separate pane</li> <li>Save as</li> <li>Print</li> <li>CAD Integrator settings</li> </ul>	Ctrl+S	

Figure 18 - Space mapping options

The spaces on the floor plan should now be coloured according to the different departments or space types, as the example below.





The reference for these colours can be found on the legend. It also displays the net area of each department or space type, as well as the **Space Usages**, i.e. the number of spaces used by each department or space type.

Under the **Components** arrow tab it is also possible to access information about the departments, such as their code and managers. This can be accessed by selecting a department, under **Departments**.



Figure 20 - Department information for Estates Division

Please note that the staff information is dependent on information from Human Resources, so it may not be up to date if the department head or manager has changed recently.

#### **Example 4: Find space types on 32LIF Basement**

- 1. On the Properties arrow tab, select 32 Lincoln's Inn Fields.
- 2. Under the **Components** arrow tab, select **Floors.**
- 3. Under the column **Floor.Code**, select **-1**.
- 4. Go to the **Spaces** arrow tab and select any space.
- 5. Turn on **CAD Integrator** (if not already on). The CAD Integrator view pane should now show a floor plan of the basement of 32 Lincoln's Inn Fields.
- 6. Use the CAD Integrator menu to select Space mapping, then Space types.
- 7. The view pane should now show a floor plan with colours according to the type of space and a legend, as below.







Figure 21 - 32 LIF Basement floor plan with space types

#### **SUGGESTIONS & TIPS**

- To print this, follow instructions described in Printing Floor Plans section.
- If the legend is not shown click the Zoom All button second from right:

and it will appear a long way from the diagram. Right click where it should be placed and select **Place legend**. This may not work, and you will have to contact Sandy Carter in the PSM team or the system administrators, who will be able to fix it.

# **Space Information Reports**

Planon can produce tables with space information directly from the program. Once a space is selected, a list of available reports can be found on the right hand side menu, by clicking the **Report** button. The spaces included in the report will be the same as are in the list on the screen.



Figure 22 - Report button on right hand side menu

You can preview each report on screen. When you have found the right one you can print it directly from Planon. It is also possible to export them and save them in different formats on a chosen location.



#### Figure 23 - Reporting options

#### Example 5: Print a report of all toilets in 32LIF

- 1. Under Properties arrow tab, select 32 Lincoln's Inn Fields.
- 2. Under Components arrow tab, click on Space Types.
- 3. Under **Space Types**, select all toilet spaces by pressing and holding **Crtl** key and clicking on space types.



Figure 24 - Selecting all toilet space types

- 4. Under **Spaces** arrow tab, click on the **Report** button to the right of screen.
- 5. On the **Reporting** prompt, choose a suitable report.
- 6. Click on **Preview report** to see report.
- 7. Click on Print user report to print directly from Planon
- 8. Click on **Save as** to export it in a different file format, such as an Excel spreadsheet.

# **More information**

A more detailed guide can be found by clicking on the **Help** button on the toolbar.



Figure 25 - Help button on top toolbar

Alternatively, contact the Estates Systems Admin team with any questions (see this guide's cover for contact information).